


WORLD MARKET®

Assembly Instructions

Zaragoza Coffee Table




SKU - 597187






THANK YOU FOR YOUR PURCHASE. IF YOU HAVE ANY QUESTIONS
PERTAINING TO THE ASSEMBLY OF THIS FURNITURE PIECE, PLEASE CONTACT
THE NEAREST COST PLUS WORLD MARKET STORE.
IF YOU ARE NOT NEAR A STORE, PLEASE CALL OUR CUSTOMER SERVICE CALL
CENTER TOLL FREE AT 877- 967-5362 FOR ASSISTANCE.

NOT FOR COMMERCIAL USE


Component List

LABEL	PICTURE	DESCRIPTION	QTY
A		TABLE TOP PANEL	1
B		LEG FRAME	2
C		CENTER STRETCHER	1

Hardware List


LABEL	PICTURE	DESCRIPTION	Q'TY
H-1		ALLEN BOLT 8x50	x6
H-2		PANHEAD SCREW 5x50	x2
H-3		ALLEN KEY	x2

Tool List

LABEL	PICTURE	DESCRIPTION	Q'TY
T-1		PHILIP SCREW DRIVER	NOT PROVIDED

Assembly Preparation

Before Beginning:



- Unpack all hardware bags and components to ensure you have all parts-



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-



- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-



- In case of missing parts, please contact your nearest Cost Plus World Market store or call our customer service call center at call 1-877-967-5362.

Assembly Steps


Step 1



(H-1) ALLEN BOLT 8x50 x3



(H-3) ALLEN KEY x1



- Place Table Top Panel (A) upside down on a padded non - marring surface.
- Attach the Leg Frame (B) to Table Top Panel (A) and secure with Allen Bolt (H-1) by using Allen Key (H-3). Do not fully tighten until all Bolts have been inserted.
- **Fully tighten all bolts using Allen Key (H-3).**

Step 2




(H-1) ALLEN BOLT 8x50 x3




(H-2) PANHEAD SCREW 5x50 x2



(H-3) ALLEN KEY x1



(T-1) PHILIP SCREW DRIVER x1



- Repeat the process from Step 1
 - Attach the Leg Frame (B) to Table Top Panel (A) and secure with Allen Bolt (H-1) by using Allen Key (H-3).
 - Place Center Stretcher (C) between Leg Frame (B) using Panhead Screw (H-2) as shown in the illustration.
 - **Fully tighten all bolts using Allen Key (H-3). and Panhead Screws using Philip Screw Driver.**
 - Turn the assembly upright and confirm all bolts and screws have been fully tightened.
- Assembly is now complete and the product is ready for use.

Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Store furniture or use an appropriate furniture cover during cold or inclement weather.



- Not for commercial use. For residential use only.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.



- Stains may be removed with mild soap solution and damp cloth.

CAUTION: As with any wood, the color may fade if left in direct sunlight or inclement weather. Minor cracking may occur with age. These are naturally occurring features of wood and do not affect product performance.

We recommend using our Outdoor Wood Furniture Finish sold separately to help preserve and protect the wood and finish.