



Contact 1.888.398.8643 for assistance.
Do not return to place of purchase.

Assembly Instructions

Model No. S-1062, S-1064

Hardware/Parts

Part	Description	Qty
1	Screen	1
2	Door Handle	2
3	Front Door	2
4	Back Foot	2
A	Screw	12
B	Nut	12

Steps

Step 1

Attach door handles to screen using 4 sets of screws (A) and nuts (B).

Step 2

Attach back feet to screen using 4 sets of screws (A) and nuts (B).

Step 3

Attach front feet to screen using 4 sets of screws (A) and nuts (B).

⚠ CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.

