





ITEM NAME / NOM D'ITEM: SHORELINE ACCENT CHAIR

ITEM # / NO.ITEM: 704042

PARTS LIST / LISTE DES PIÈCES

(1)	(2)
 <p style="text-align: right;">×1</p>	 <p style="text-align: right;">×1</p>

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE



Please use the attached adjustable footglides to level the chair on uneven surface.