


# WORLD MARKET®

## Assembly Instructions

BRONZE 2 TIER FLOOR LAMP W/SHADE




SKU # 644567



Thank you for your purchase. If you have any questions pertaining to the assembly of this lighting piece, please contact the nearest World Market store. If you are not near a store, please call our customer service call center toll free at 877-967-5362 for assistance.


ALL PRODUCTS SOLD AT WORLD MARKET ARE NOT  
FOR COMMERCIAL USE AND ARE INTENDED FOR  
RESIDENTIAL USE ONLY.

## Component List

LABEL	FIGURE	DESCRIPTION	QTY
A		UNO RING	1
B		LAMP BASE	1
C		FABRIC SHADE	1

## Assembly Preparation

Before Beginning:



Remove the Uno Ring (A) from the light socket by unscrewing it counter clockwise.



Unpack all hardware bags and components to ensure you have all parts. Take note of bolt hardware size differences and components that may have directional labels (Example: TOP or FRONT).



Read the assembly instructions, cover-to-cover. Save any **Care and Maintenance** instructions pages for after the assembly has been completed.



Do not assemble on hard, abrasive flooring or carpeted surfaces that can damage or get caught in the components during assembly.



Assemble on a clean non-marring surface (such as the product's packing foam).



Do not discard any packaging until the product has been fully assembled.




In case of missing parts, please contact your nearest World Market store or call our customer service call center at 1-877-967-5362.



**WARNING:** Small parts are a choking hazard. Adult supervision is required before, during, and after assembly.

# Assembly Steps


## STEP-1



## Step 1

Align each stem section of Lamp Base (B) with each other as shown. Rotate each section clockwise until secured. **DO NOT OVER TIGHTEN.** Gently adjust the cord length at the base as needed.


## STEP-2



## Step 2

Remove the preinstalled Uno Ring (A) from the socket by rotating counter clockwise. Place the Glass Shade (C) onto the socket and secure by re-installing the Uno Ring (A). **DO NOT OVER TIGHTEN.**

## Bulb Installation



Insert Bulb (not included) into the socket and rotate it in clockwise to secure. Plug the cord into a near by electrical socket and check for proper lighting operation. Assembly is now complete and the product is ready for use.

## Warnings



All products sold at World Market are not for commercial use and are intended for residential use only.



To prevent the risk of fire, DO NOT use light bulbs with wattage greater than 60 Watt and 13 watt LED. Use Type A Bulb for this product. Bulbs sold separately.



Lamp shade is not included. Use the Lamp Shade Guidance above to source a shade appropriate for the bulb application type.



Never turn on power to the lamp until light bulb has been installed and assembly is completed.

## Care & Maintenance



**DO NOT** clean furniture with harsh cleansers or polish.



**DO NOT** place fixture outside. For INDOOR USE ONLY.



Fixture can be dusted using a clean, non-colored, lint-free dry cloth.

"NOTE: This product is a handcrafted item and natural/subtle variations may be present in the finish or craftsmanship. These aesthetic variations do not impact the use of the product."