


# ASSEMBLY INSTRUCTIONS FOR Zeek Floor Lamp

Model # 3889-01

3889-01 1.0



1. Screw pole(B) clockwise into base(A) to tighten.
2. Screw pole(C) clockwise into pole(B) to tighten.
3. Screw socket part(D) clockwise into pole(C) to tighten.
4. Socket ring(F) comes pre-assembled to the socket. Before assembling the shade, please unscrew this socket ring(F). Set shade(E) onto socket and tighten clockwise with socket ring(F) to secure shade.

## GENERAL PRODUCT INFORMATION:

This product is suitable  
for dry locations only.



## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE : (1) 150 watt 3-way incandescent or  
18 watt 3-way LED bulb (not included)