




1. Screw part(B) clockwise into base(A) to tighten.
2. Attach the harp(C) on the socket.
3. Set the shade(D) on the harp(C) and tighten clockwise with the finial(E).

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE: (1) 100 watt 3-way maximum incandescent or 18 watt 3-way maximum equivalent LED bulb.(not included)