


ASSEMBLY INSTRUCTIONS

ITEM NO: BO-3007FL

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

1. SCREW POLE (D) CLOCKWISE INTO POLE (E) TO TIGHTEN.
2. SCREW POLE (E) CLOCKWISE INTO POLE (F) TO TIGHTEN.
3. SCREW POLE (F) CLOCKWISE INTO THE BASE (G) TO TIGHTEN.
4. PLACE SHADE (B) ONTO THE SOCKET (A), THEN SCREW IT BY SOCKET RING (C) CLOCKWISE TO TIGHTEN.
5. LOOSE THE KNOB (H) TO ADJUST THE ARC POLE (D) TO DESIRED HEIGHT AND TIGHTEN AGAIN.
6. INSTALL BULB (NOT INCLUDED) INTO THE SOCKET.
7. INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY !!



Use MAX 40 Wattage type A bulb (Bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.