

HULALA

HOME


Thank You For Choosing Our Furniture

- ▀ If you have any questions or concerns, don't hesitate to reach out to us.

Call us: +1(833)324-2464
Email: hello@hulalahome.com

NOTE:

▀ This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



ITEM NO. TVSBSD0505



Installation:
30 minutes.



MAINTAINANCE AND WARNINGS



Before You Start

Please follow the steps below:

-  Check the packaging for any damage, deformation, or water stains. If there is significant damage, please contact us promptly.
-  Open the packaging and confirm that the panels, hardware, screws, etc are complete.
-  Please read the installation instructions carefully to understand the installation steps and precautions to ensure proper installation.
-  Clean the installation area in advance and ensure the ground is level and there is enough space to avoid damaging the furniture or making installation difficult.
-  Lay a protective mat on the ground to prevent scratching the floor during installation.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Precautions

- ⚠ This product is for indoor use only. Do not expose it to outdoor elements or high-humidity environments.
- ⚠ Keep the cabinet away from high heat or open flames to prevent fire hazards.
- ⚠ Do not allow children to climb on the product, as this may cause tipping and result in personal injury.



Safety Warnings


- ⚠ If you notice any loose or damaged parts, stop using the product immediately and contact customer service.
- ⚠ Do not attempt to disassemble or replace any components yourself, as this may affect the stability and safety of the product.

Daily Maintenance













- Regularly clean the surface with a soft cloth to prevent dust accumulation.

Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners
- Avoid exposing furniture to humid environments for extended periods to prevent swelling or deformation of the boards. Use a dehumidifier or desiccant during humid weather.
- Avoid direct contact of furniture with water. If water is accidentally spilled, wipe it dry immediately.
- Avoid placing excessively heavy objects on the furniture: ensure the weight is within a reasonable load-bearing range.
- Avoid using sharp or rough items on the furniture surface to prevent scratches. Handle items gently when moving them



Explosive view









Parts list


A x1 Top panel 	B x1 Bottom panel 	C x1 Left side panel 
D x1 Right side panel 	E x1 Middle left panel 	F x1 Middle Right panel 
G x2 Side shelf panel 	H x1 Middle shelf panel 	I x2 Side back panel 
J x1 Middle back panel 	K x1 Left door panel 	L x2 Middle & right door panel 

Parts list

M x2 Cabinet leg 	N x1 Connecting bar 	O x2 Center leg 
---	--	--














Hardware List

①x8 Cambolt  Ø6x33mm	②x8 Camlock  Ø15x9.5mm	③x8 Hex screw  Ø6.5x48mm
④x16+1 Dowel  Ø8x30mm	⑤x67+3 Screw  Ø3.5*14mm	⑥x4 Hinge 




Note: Before installing the screws, please first distinguish the length of the screw rods.

Hardware List

⑦x2 Hinge 	⑧x18 Corner bracket 	⑨x12 Shelf pin 
⑩x3 Push latch 	⑪x8 Sticker  Ø20	⑫x1 Hex key  M4
⑬x4 Screw  Ø4x35mm	⑭x4 Anti-tip furniture bracket 	⑮x2 Cable tie 
⑯x4 Wall plug 	⑰x1 Screwdriver 	⑱x8 Hex screw  Ø1/4"x50mm
⑲x2 Hex screw  Ø1/4"x40mm		

Step 1

Place panel A on clean padded surface. Use screwdriver ⑰ and screw ⑤ to connect push catch ⑩ with panel A, insert wood dowel ④ into panel A, use screwdriver ⑰ to connect cam bolt ① with panel A, make sure all holes aligned and fasten all screws to secure



④	x8
Ø8*30mm	

⑤	x6
Ø3.5*14mm	



⑩	x3


⑰	x1


①	x8
Ø6x33mm	


Step 2

Use screwdriver ⑰ and cam lock ② to connect panel C,D,E,F with panel A,make sure all parts aligned and fasten all cam lock ② to secure,then cover the cam lock ② with sticker ⑪.




⑰	x1
	


②	x8
	
Ø15x11mm	

⑪	x8
	
Ø20mm	

Step 3


With help of adult partner insert panel I & J into the grooves of panel D,F,E,C,insert wood dowel ④ into panel C,E,F,D make sure panel I & J properly set into grooves on panel D,F,E,C,A.





④	x8
	
Ø8x30mm	

Step 4


Use allen key ⑫ and bolt ③ to connect panel B with assembled unit A,C,E,F,D,make sure all parts properly aligned and fasten all bolts to secure.





③	x8	⑫	x1
			
Ø6.5x48mm		M4	

Step 5


Prepare the leg racks. Align the holes of the M part with the holes of the N part, install the screw ①⑨, and tighten the screw ①⑨ with the allen key ①⑫.




①⑨	x2	①⑫	x1
			
Ø1/4"x40mm		M4	


Step 6

Connect the leg frame to the cabinet. Attach the leg frame to the pre-assembled unit in step 4 with a screw ⑮ and tighten with a allen key ⑫.




Do not fully tighten bolts until all bolts are in position!!!

⑮	x8
	
Ø1/4"x50mm	

⑫	x1
	
M4	




Step 7

Connect the middle legs to the cabinet. Attach the middle legs to the pre-assembled unit in step 6 and hand tighten.




Step 8

Insert shelf pin ⑨ into reassemble unit at step 4. attach adjustable shelf (G, H, G) to pin ⑨








Step 9

Use screwdriver ⑰ to connect screw ⑤ with round metal catch ⑩ and hinge ⑥ on left door panel K & right door panel L, fasten to secure.




When installing hinge, please pay attention to distinguish the category of hinge








Step 10

Use screwdriver ⑰ to connect screw ⑤ with round metal catch ⑩ and hinge ⑦ on center door panel L, then fasten to secure.






When installing hinge, please pay attention to distinguish the category of hinge




Step 11


Use screw ⑤ to attach left (K) and right door (L) to reassemble unit at step 9 ,tighten screw with screwdriver ⑰ .



Step 12


Use screw ⑤ to attach middle door (L) to reassemble unit at step 10 ,tighten screw with screwdriver ⑰ .




⑰	x1	⑤	x8
			
		Ø3.5x14mm	

Step 13


Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!



Concealed hinges are three-way adjustable:




Vertical via slots in
the mounting plate
or via cam adjustment!



Hinge adjustment method

Step 14



Attach part ⑧ to parts I, J, I with bolt ⑤ and tighten the bolt with screwdriver ⑰.




⑧	x18	⑰	x1	⑤	x18
				Ø3.5x14mm	

Step 15


Install Anti-tip device ⑭ to the wall in this step.







1. Drill a hole in the wall with an electric drill.







2. Tap the plastic wall anchor into the hole with a hammer.




3. Secure the Anti-tip device ⑭ to the wall with screws ⑬.



Step 16

⑤	x4	⑭	x2	⑮	x2	⑰	x1
							
Ø3.5x14mm							

Attach part ⑭ to parts D, C with bolt ⑤ and tighten the bolt with screwdriver ⑰. Mark the position on the wall, that corresponds to the location of part ⑭ on the side panel D,C; Drill and insert the expandable screw ⑬ by hammer. Assemble the part ⑭ to the wall. Align the hole in the part ⑭ with the expandable screw ⑬, use screw ⑬ to attach it and tighten by screwdriver ⑰. Let the plastic belt ⑮ pass through the both part ⑭ and pull tightly.



WARRANTY

- We strive to offer quality products, and we also try our best to satisfy every customer who orders from us with products or services as needed.
- Replacement parts can be purchased from our company if available.
- For returns, please check the return policy with the retailer or marketplace where you purchased the item.

Are you having difficulty

With assembly? Missing parts?
Please send an email with your order No. to
hello@hulalahome.com

We appreciate your purchase.
Brighten your life with our furniture!